# MY LAPTOP IS NOT PROJECTING PROPERLY!

When the laptop is not showing what you would like it to display, it is probably because your display setting is not set to mirror. The steps below will help you change your setting.

STEP 1: Click on the ***black apple*** at the top, left hand side of

your screen and ***choose*** **System Preferences**.

STEP 2: ***<u>With your laptop connected to the projector,</u>***

And choose Displays from within the System

Preference window.

STEP 3: Click on **Arrangement** within the Display window.

STEP 4: Make sure that the **Mirror Displays Box** is *checked*.